

10 Before calling for service

Problem	Possible cause	Solution
Completely fails to work	Is there a power outage? Is the power cord unplugged? Are you sitting on the seat correctly?	Check for a power failure or a tripped breaker Plug the power cord in properly Sit on the seat correctly to activate sensor.
Water does not spray	Is the water shutoff valve closed? Is the strainer clogged? Are the nozzles clogged? Is the water purifying filter clogged?	Check for any water leaking or dripping Clean the strainer Clean the nozzles Change the water purifying filter
Water is leaking or dripping	Are all hoses tightened properly?	If water is still leaking or dripping, contact your dealer
Seat, water or air is not warm enough	Is the temperature set to OFF? Is the appliance set on economy mode?	Reset the temperature Release the economy function

11 Specifications

Item	UB-6800	
Standard power supply	AC 120V 60Hz 660W	
Water supply	Way of connection	Direct connection to tap water
	Water pressure	0.08MPa ~ 0.75MPa
Cleansing	Spray for cleansing	900 ± 100ml/min
	Spray for bidet	900 ± 100ml/min
	Water capacity	800 ml
	Spray temperature	Room Temp ~ 40°C (104°F)
	Heater capacity	600W
	Safety feature	Thermal switch, Temperature fuse, Floating switch
Dry	Air temperature	Room temp ~ 60°C (140°F)
	Heater capacity	250W
	Safety feature	Temperature fuse
Heated seat	Seat temperature	Room temp ~ 40°C (104°F)
	Heater capacity	55W
	Safety feature	Temperature fuse
Deodorization method	Catalytic filter	
Circuit breaker	Within 15mA 0.03 second	
Length of power cord	1.2m	
Dimensions	Elongated	(W)392mm X (L)520mm X (H)143 (W)15.43inch X (L)20.47inch X (H)5.62inch
	Round front	(W)392mm X (L)500mm X (H)143 (W)15.43inch X (L)19.68inch X (H)5.62inch
Weight	4.4Kg(9.7lbs)	

※ Recommended water supply pressure is 0.1MPa~0.69MPa

※ Under 0.1Mpa pressure, water spray pressure might not be adequate.